

SMART DOORBELL CHIME





The chime connects to our Wi-Fi Video Doorbell to alert you when the door bell has been pressed.

- Comes with multiple tones, select different tones for different notifications.
- Easily control the volume so you can hear all over the house.
- 4 Levels of adjustable volume with 38 customisable chime sounds plus a silent mode.
- Plugs into any standard power outlet.
- Works up to 20m distance away from the Smart WiFi Video Doorbell.

In-home alert when your Video Doorbell is activated



APPLICATIONS

Only works in conjunction with BrilliantSmart WiFi
Video Doorbell



Brilliant SMART DOORBELL CHIME

TECHNICAL SPECIFICATIONS

240V / 50Hz				
Class II (2)				
RF 433.92MHz				
5 Levels				
38 options Select alternate tones for different events				
10-15m (30m open area)				
ABS / Polycarbonate				
5°C to 30°C				
1 year replacement				
AS/NZS 60950 AS/NZS 4268 AS/NZS CISPR 32 AS/NZS 3112				

ACCESSORIES (sold separately)


Video Doorbell:

20761/06

INSTALLATION

Do-it-Yourself installation





	MODEL	COLOUR	DESCRIPTION	BOX SIZE	GROSS WEIGHT	BOX QTY	BARCODE/TUN
RETAIL BOX	21387/06	Black	Smart Doorbell Chime	W105 x H188 x D60 mm	0.11 kg	1 pc	9 312641 213871 >
OUTER CTN	21387/06	Black	Smart Doorbell Chime	W490 x H275 x D430 mm	5.00 kg	42 pc	19312641213878