INSTALLATION GUIDE

Product code: WL8-CCT-White-1

8 W Up/Down Indoor LED Wall Light – White, Tricolour

240 V hard-wired product: it must be installed by a licensed electrician to AS/NZS 3000.

IN THE BOX


- 1 × up/down wall light with built-in driver and mounting bracket
- Wall plugs, screws and Allen key

YOU WILL NEED

- Drill and masonry bit
- Screwdriver
- Spirit level
- Wire stripper

BEFORE YOU START

- Turn off the power at the switchboard and test it is dead.
- Indoor, dry rooms only – not for bathrooms near water or outdoors.
- If dimming, use a phase-cut (triac) LED dimmer and ask your electrician to check its minimum load suits the number of lights.



STEP BY STEP

1. Loosen the small screws at each end with the Allen key and lift the light off its mounting bracket.
2. Hold the bracket level on the wall with its arrow pointing up. Mark and drill the holes, fit wall plugs.
3. Feed the cable through and screw the bracket to the wall.
4. Connect Active (L), Neutral (N) and Earth to the terminal block.
5. Set the colour switch to 3000 K, 4000 K or 5700 K.
6. Fit the light back on the bracket and tighten the end screws.
7. Turn the power on and check the light and dimmer.

SETTINGS & USE

- Colour switch (on the back): 3000 K warm, 4000 K natural or 5700 K bright white.

DO NOT

- Don't install outdoors or in wet areas (IP20).
- Don't use a dimmer that isn't rated for LED lights.
- Don't cover the top or bottom opening.

CARE & TROUBLESHOOTING

- Dust with a soft dry cloth.
- If it flickers when dimmed, ask your electrician to check the dimmer.

Installation: Greenhse recommends that every product is installed by a licensed electrician to AS/NZS 3000 and local rules. Any work on 240 V wiring must be done by a licensed electrician. Incorrect installation can be unsafe and may void the warranty. **Warranty:** 2 years. Keep your invoice and the electrician's certificate of compliance. Questions? Call (08) 9297 2969 or visit greenhse.com.